



UPPER VALLEY EVENTS CENTER

Your Indoor & Outdoor Facility
Events • Meetings • Classes • Parties

Bouncy Castle

Capacities

Ages 0 - 8, 8 to 10 can jump

Ages 9 - 12, 4 to 6 can jump

Teenagers, 3 to 4 can jump

Adults, 2 can jump

Rules

- Same Size Jumpers only - no big kids with little kids
- No flips, somersaults or rough play
- No shoes or sharp objects
- No food, drinks or gum
- No eyeglasses or jewelry
- No operation in the rain
- No operation in high winds
- Must be supervised by adult at all times



UPPER VALLEY EVENTS CENTER

Your Indoor & Outdoor Facility
Events • Meetings • Classes • Parties

Bouncy Castle

Set Up Instructions

All directions are relative to you facing towards woods. Two people minimum.

Unlock and free the hasp on the storage box. Combination is 7783. Turn latch handle on top surface towards you. Lift carefully the top to open it up.

Place blower on stage to your right. Unwrap cord and plug it into outlet on outside skirt of stage. Immediately test blower - switch is tucked next to blower neck and is black. If blower doesn't turn on, check GFCI reset button on outlet. Try another outlet if still no power.

Pull out folded castle. Take two red straps and place one around tree (see image) and other around base of bench/railing system. These will connect to the two corners of castle after inflation to ensure that it does not move. Both are adjustable.

Arrange castle so that one of the green sleeves fits over blower (move blower as necessary). Strap sleeve around blower neck - should be tight. Seal off other sleeve with its strap.

Arrange castle as best you can centered in stage. Turn on blower. Within a few minutes the castle will be fully inflated. Move it and connect red straps to "D" rings on corners. Snug them up to ensure the castle cannot move towards the back railing and the storage box.

Questions call Bruce Genereaux on his cell phone at (603) 553-7977 any time.

UPPER VALLEY EVENTS CENTER

Your Indoor & Outdoor Facility
Events • Meetings • Classes • Parties

Bouncy Castle



Blower Location and
outlet to right, over edge



Set up castle. Note ramp in front, tie-down
straps attached from each front corner to tree
(left) and post (right).



Tie red straps to tree
(left) and post (right)



UPPER VALLEY EVENTS CENTER

Your Indoor & Outdoor Facility
Events • Meetings • Classes • Parties

Bouncy Castle

Take Down Instructions

Get all children out of castle and onto grass.

Turn off blower. Watch out for falling castle towers!

Disconnect sleeves from blower and untie extra sleeve.

Ask children to walk on top of deflating castle to get all air out of it. DON'T let children jump as they crash all the way to the deck now.

Disconnect red straps from tree and post.

Once castle is mostly deflated, drag castle towers to center in crossing pattern. It is OK to walk on castle with your shoes.

Now, with two strong people, fold the outsides toward the center - your objective is to get it in thirds.

Once you have it in thirds - have kids walk and roll on it to push out air, then roll it up from front to back. This is tough. Then drag it into box. Place rest of equipment in box and lock it.

If castle went away wet, please let Bruce know so he can get it out on a sunny day and dry it off.